

DONNEES TECHNIQUES

Length [mm]	589
Number of splines (wheels side)	25
	for vehicles without ABS
(wheels side) CV Joint Ø [mm]	72
Number of splines (gearbox side)	23
(gearbox side) CV Joint Ø [mm]	78
(gearbox side) shoulder Ø [mm]	40

PHOTOS



DOCUMENTS

BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions

APPLICATIONS

FORD		
KA (96-08) (RB_) - 1.0 i	52 ch	07.1997 > 09.1999
	65 ch	09.1999 >
KA (96-08) (RB_) - 1.3 i	49 ch	06.1998 >
	50 ch	09.1996 > 10.2002
	60 ch	09.1996 >
	70 ch	08.2002 >

⚠ Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.